

YOUR SAFETY &
INSTRUCTION MANUAL
PLEASE READ CAREFULLY

LED
ILLUMINATED
MIRROR
MODEL C85001

3^{*}
YEAR
GUARANTEE



CARMEN



TECHNICAL DATA

Description: LED Illuminated Mirror
Model: C85001
Power: 4.5V - 3x AA batteries (not included)

DOCUMENTATION

We declare that this product conforms to the following product legislation in accordance with the following directive(s):

2004/108/EC Electromagnetic Compatibility Directive.
2011/65/EU Restriction of Hazardous Substances Directive.

RKW Quality Assurance, United Kingdom

WARRANTY

This product is guaranteed for 12 months from the date of original purchase. If any defect arises due to faulty materials or workmanship, the faulty products must be returned to the place of purchase. Refund or replacement is at the discretion of the retailer.

The following conditions apply:

- The product must be returned to the retailer with proof of purchase.
- The product must be installed and used in accordance with the instructions contained in this instruction guide.
- It must be used only for domestic purposes.
- It does not cover wear and tear, damage, misuse or consumable parts.
- RKW has limited liability for incidental or consequential loss or damage.
- This guarantee is only valid in the UK and Ireland Only.

AN EXTENDED WARRANTY IS AVAILABLE FOR THIS APPLIANCE. SEE BACK PAGE FOR DETAILS.

Product safety

When using **any** electrical appliance, basic safety precautions should always be followed including the following:

- Check that the voltage of the main circuit corresponds with the rating of the appliance before operating.
- Please ensure that the appliance is used on a stable, level, and heat resistant surface.
- Do not immerse cords, plugs or any part of the appliance in water or any other liquid.
- Do not leave the appliance unattended while it is operating.
- Close supervision is necessary when any appliance is used by or near children or pets.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Switch off at the wall socket then remove the plug from the socket when not in use or before cleaning.
- If the supply cord or appliance is damaged, stop using the appliance immediately and seek advice from the manufacturer or its service agent or a similarly qualified person.
- Do not let the cord hang over the edge of a table or counter or let it come into contact with any hot surfaces.
- The use of accessory attachments is not recommended by the appliance manufacturer, apart from those supplied with this product.
- Do not pull the plug out by the cord as this may damage the plug and/or the cable.
- Do not use this product for anything other than its intended use.
- This appliance is for household use only.



- Do not use the appliance outdoors.
- In the event where the appliance is dropped into the water, turn off the power at the power outlet and remove the plug immediately. **DO NOT REACH INTO THE WATER TO RETRIEVE IT.**
- Young children should be supervised to ensure that they do not play with the mirror.
- Do not use the mirror for any purpose other than its intended use.
- Do not place the mirror on or near a flammable or hot object.
- Place the mirror on a flat and even surface.
- Do not use the mirror if it has been dropped or damaged in any manner
- If damage is suspected, please call the helpline number.
- Do not use the mirror near baths, basins or other vessels containing water or other liquids.
- The mirror is designed for domestic use only.
- Always switch the power off after using the mirror and remove the batteries if the mirror is not to be used for a long period of time.
- Never submerge the mirror in water or any liquid.
- Always ensure that the battery compartment is dry to avoid corrosion of the components.
- In the unlikely event the appliance develops a fault, stop using it immediately and seek advice from the service department:
+44 (0) 871 221 3622



DISPOSAL OF THE UNIT



Appliances bearing the symbol shown here may not be disposed of in domestic rubbish. You are required to dispose of old electrical and electronic appliances like this separately.

Please visit www.recycle-more.co.uk or

www.recyclenow.co.uk for access to information about the recycling of electrical items. Please visit www.weeeireland.ie for access to information about the recycling of electrical items purchased in Ireland. The WEEE directive, introduced in August 2006, states that all electrical items must be recycled, rather than taken to landfill.

Please arrange to take this appliance to your local Civic Amenity site for recycling, once it has reached the end of its life.

WHAT'S IN THE BOX

Instruction Manual

Illuminated Mirror

1. LED Bulb Cluster

2. On/Off Switch

3. Power Socket

(optional. The power adaptor is not included with this product. A universal adaptor can be purchased from any good electrical suppliers. See using your appliance for correct adaptor rating)



BEFORE YOUR FIRST USE:

1. Remove your Illuminated Mirror from the packaging.
2. Check that there is no damage to mirror.
3. Insert 3 x (AA) batteries

Dispose of the packaging in a responsible manner.

WARNING: DO NOT IMMERSE THE UNIT IN WATER.

USING YOUR APPLIANCE

Your mirror works with 3 AA – 1.5 V batteries which are not included in the box.

(Note : AC Power adaptor is not included, however you can use a AC power adaptor with an input of 230-240V and output of 4.5V 500mA.)

To install or remove the batteries

- Remove the cover of the battery compartment located under the base of the mirror. Insert 3 AA – 1.5 V batteries, ensure that the polarities on the batteries match the polarities as indicated on the mirror. Close the cover.

Note: Always new batteries. Do not use old and new batteries at the same time.

- To remove the batteries, ensure that the switch is in the “OFF” position. Open the battery compartment cover, remove the batteries and then close the cover.

Activating the Mirror LED Cluster

- To activate the LED cluster, set the switch to the “ON” position.
- To switch off the LED cluster, set the switch to the “OFF” position.

Note: This mirror may be used as a regular mirror when there are no batteries fitted or when it is switched to the “OFF” position.

CLEANING YOUR APPLIANCE

- Clean the body of the mirror with a soft and dry cloth.
- Never use a damp cloth.
- Mirror surfaces must be cleaned with a soft cloth.
- Do not clean the body or the mirror with any detergent.
- Store your mirror in a cool, dry place. Do not place the mirror directly in sunlight.

NOTES:



**We hope you enjoy your
appliance for many years.**

As a thank you for purchasing
one of our fantastic products,
we are giving you an extra
2 years peace of mind.

To receive your extra 2 years
guarantee, register your
appliance online by visiting
www.carmenproducts.co

Thank You!

3^{*}
YEAR
GUARANTEE

**Should you have a problem
with your appliance or need any
spare parts please call our
Service Department on:**

+44 (0) 871 221 3622

**Distributed throughout the UK
by RKW LTD**

CARMEN